HONDA

How to:

Programming your HomeLink Feature.

1 Position the remote transmitter you wish to link 1-3 inches (3-8 cm) from the HomeLink button you want to program.

2 Press and release the desired HomeLink button. Hold the button on the remote transmitter.

Does the HomeLink indicator (LED) change from slowly blinking to constantly on or rapidly blinking? This should take less than one minute

NO

YES

A Press and release the HomeLink button. Press and release the button on the remote every 2 seconds.

Does the LED change from slowly blinking to constantly on or rapidly blinking? This should take less than one minute.

NO

YES

3 Press and hold the programmed HomeLink button for about a second. Does the device (garage door opener) work?

NO

YES

Training Complete

4 Press and hold the HomeLink button again.

HomeLink indicator rapidly blinks.

HomeLink LED remains on.

A The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g., garage door opener).

B Within 30 seconds, press and hold the programmed HomeLink button for 2 seconds.

5 Press and hold the HomeLink button again; the remote-controlled device should operate.Training complete.

For more help with HomeLink visit
HomeLink.com