

Customize Interior Light-Dimming Time

7" Color Touch-Screen Models

This vehicle lets you customize how long the interior lights stay on after the doors are closed.

- 1 Make sure the power is ON and the transmission is in PARK.
- 2 Roll the selector wheel on the right side of the steering wheel until Vehicle Settings appears in the digital instrument cluster, and push to select it.
- 3 Now scroll to Lighting Setup, and push.
- Next, select Interior Light Dimming Time.
- 5 Choose 60 sec, 30 sec or 15 sec.
- Finally, scroll to and select the Back arrow until you return to the normal screen.





