



How to Use Car-Wash Mode

When sending your vehicle through a conveyor-type car wash with no one behind the wheel, you'll need to put it in car-wash mode. Here's how:

- 1 With the engine running and your foot on the brake pedal, push and release the N button to shift into NEUTRAL—a message will appear in the instrument panel.



- 2 Now press the N button again and hold it for two seconds; a new message will appear in the instrument panel indicating "Neutral-Hold Mode ON."



- 3 To cancel car-wash mode, press the P button to shift into PARK.



IMPORTANT NOTES:

Car-wash mode can remain engaged for a maximum of 15 minutes; after that, the transmission will automatically shift into PARK and the power mode will switch to OFF.

When the transmission is too hot, car-wash mode may not be available; let the engine idle until the transmission temperature is sufficiently reduced.