$(\mathbf{H})$ 

HONDA

## **Use Interior Lights**



Map Light Button

**Overhead Switch** 

Map Light Button

## Front & Rear Overhead Lights

The front and rear overhead-light switches in this vehicle work the same way. Three settings can be selected:

ON: With this setting, the interior lights come on regardless of whether the doors are open or closed.

DOOR: This setting activates the lights when:

- Any door is opened
- The driver's door is unlocked
- The power mode is switched OFF

OFF: When this setting is selected, the lights remain off at all times.

## **Map Lights**

The map lights are turned on and off by simply pressing their respective switches.



Rear Overhead Light

See your vehicle's Owner's Manual for even more details. You can download one at mygarage.honda.com.