

Adjust and Use the Power Door Mirrors

The driver and passenger power door mirrors are easy to adjust using the LEFT/RIGHT SELECTOR SWITCH and the MIRROR-POSITION ADJUSTMENT SWITCH found on the driver's side armrest or dash. And on select models the passenger-side mirror can be activated to tilt down when the transmission is put into reverse for better viewing while backing up.

Follow these steps:

Mirror Position Adjustment

- 1 Using the LEFT/RIGHT SELECTOR SWITCH, select the side mirror you want to adjust
- 2 Using the MIRROR POSITION ADJUSTMENT SWITCH, press the switch left, right, up or down to move the mirror to the position you desire
- 3 When finished, return the left/right selector switch to the center position

Reverse Tilt Door Mirror

- 1 To activate this feature, set the Power Mode to ON and slide the SELECTOR SWITCH to the passenger side door mirror
- 2 When you put the transmission into REVERSE gear, the mirror tilts down and improves close-in visibility of the passenger side of the vehicle
- 3 The mirror automatically returns to the original position when the transmission is taken out of reverse

Folding Door Mirrors

- 1 On select models there is a FOLDING button near the selector switch; press it to fold the mirrors in and out (used for navigating or parking in a tight space).



For more information see, your Owner's Guide.

*Honda Pilot shown to demonstrate operation

