

Adjust and Use the Power Door Mirrors

The driver and passenger power door mirrors are easy to adjust using the LEFT/RIGHT SELECTOR SWITCH and the MIRROR-POSITION ADJUSTMENT SWITCH found on the driver's side armrest or dash. And on select models, either side mirror can be activated to tilt down when the transmission is put into reverse for better viewing while backing up.

Follow these steps:

Mirror Position Adjustment

- 1 Using the LEFT/RIGHT SELECTOR SWITCH, select the side mirror you want to adjust
- 2 Using the MIRROR POSITION ADJUSTMENT SWITCH, press the switch left, right, up or down to move the mirror to the position you desire
- 3 When finished, return the left/right selector switch to the center position

Reverse Tilt Door Mirror

- 1 To activate this feature on select models, set the Power Mode to ON and slide the SELECTOR SWITCH to the side on which you want the mirror to tilt
- 2 When you put the transmission into REVERSE gear, the mirror tilts down and improves close-in visibility of the side of the vehicle
- 3 The mirror automatically returns to the original position when the transmission is taken out of reverse

Folding Door Mirrors

- 1 On select models there is a FOLDING button near the selector switch; press it to fold the mirrors in and out (used for navigating or parking in a tight space).



For more information see, your Owner's Guide.