

How to Customize Interior Light-Dimming Time –Models with 7" Driver Information Interface (DII)

Honda vehicles equipped with the 7" Driver Information Interface (DII) enable you to customize certain settings, including how long the interior overhead light stays on after closing the doors. Use the steering wheel-mounted switches on the left to customize the lighting with the DII.



Home Button

Follow these steps:

1. With the vehicle in **Park**, turn the ignition to **Accessory** or **On**
2. Press the **HOME** button
3. Rotate the **SELECTOR WHEEL** to scroll to **Settings**; then press
4. Rotate the **SELECTOR WHEEL** to scroll to **Lighting Setup**; then press
5. Rotate the **SELECTOR WHEEL** to scroll and select **Interior Light Dimming Time**; then press
6. Select from: **60sec**, **30sec**, **15sec**; then press
7. Press the **HOME** button to exit