

How to Adjust the Power Door Mirrors



To enhance awareness while driving, make sure the door mirrors are adjusted properly. Here's how they work.

- First, make sure the driver's seat is properly adjusted
- Press the mirror-adjustment button on the left side of the driver's armrest to adjust the driverside mirror; an indicator light will come
- Press the arrows on the control pad to move the mirror to your preferred position
- Press the left mirror-adjustment button to deselect the mirror
- Press the right mirror-adjustment button to adjust the passenger-side mirror, and repeat the above steps