

How to Adjust the Power Door Mirrors



To enhance awareness while driving, make sure the door mirrors are adjusted properly. Here's how they work.

- 1 First, make sure the driver's seat is properly adjusted
- 2 Press the mirror-adjustment button on the left side of the driver's armrest to adjust the driver-side mirror; an indicator light will come
- 3 Press the arrows on the control pad to move the mirror to your preferred position
- 4 Press the left mirror-adjustment button to deselect the mirror
- 5 Press the right mirror-adjustment button to adjust the passenger-side mirror, and repeat the above steps

See your vehicle's Owner's Manual for even more details. You can download one at mygarage.honda.com.

2024 Prologue Elite shown